

Model 101 Assembly Instructions



MATERIALS RECOMMENDED

5 — 2"×10" - 5'-8' in Length

ASSEMBLY INSTRUCTIONS

Place frames and top boards in upside down position. Center the frame in from each edge and in from the ends 6" – 18" depending upon the length of the table. With end frames square, position the braces (centered edge to edge) on the center boards. Drill and bolt frames and braces. Do not tighten bolts at this point. Turn table upright and center seat boards on seat brackets. Drill and bolt, then tighten all bolts.